


DC9257L- Custom default + SENSE MODE



1 . 0006010

(Start configuration)



2. Custom default



3 . 0302010

Sense mode



4. 0006000

(End configuration)